



aerospace climate control electromechanical

iltration

fluid & gas handling hydraulics pneumatics process control sealing & shielding





# **Portable Filter Carts**

Models 5MFP & 10MFP with Moduflow  $^{\text{TM}}$   $\mathcal{P}$  (u.s.





ENGINEERING YOUR SUCCESS.



### Applications for Portable Filter Carts

- Filtering new fluid before putting into service
- Transferring fluid from drums or storage tanks to system reservoirs
- Conditioning fluid that is already in use
- Complimenting existing system filtration
- Removing free water from a system
- For use with fluids such as hydraulic, gear and lube oils

Our portable filter carts are the ideal way to prefilter and transfer fluids into reservoirs or to clean up existing systems.

Fluid should always be filtered before being put into use. New fluid is not necessarily clean fluid. Most new fluids (right out of the drum) are unfit for use due to high initial contamination levels. Contamination, both particulate and water, may be added to a new fluid during processing, mixing, handling and storage.

Water is removed by installing Par-Gel™ elements in the outlet filter. Par-Gel™ elements are made from a polymer which has a very high affinity for free water.

Once water comes into contact with this material, it is removed from the system.


The portable filter cart uses two high capacity ModuFlow™ Plus filters for long element life and better system protection. The first stage (inlet) filter captures larger particles, while the second stage (outlet) filter controls finer particles or removes water. A rugged industrial quality gear pump gets the job done fast.

Using a portable filter cart is the most economical way to protect your system from the harm that can be caused by contamination.

Features	Advantages	Benefits
Two filters instead of one w/ 2.5 times increased DHC	Pump protection and long element life	Element cost savings and trouble-free service
Wide variety of particulate elements available	Capable of getting a fluid to a desired cleanliness level	Extends fluid life and system performance
<ul> <li>Par-Gel™ water removal elements available</li> </ul>	Removes "free water" from a system	Gets dirt and water out of system with one process
Heavy duty frame	Rugged and durable	Built to last for many hours of use
Lightweight and portable	Easy to move from place-to-place	One person operation
<ul><li>Two flow rates available:</li><li>5 gpm or 10 gpm</li></ul>	Enables use in low or high viscosity applications	Matched to your needs
Eleven-foot hose and wand assemblies included	Additional hardware not necessary	Ready to use as received



### **Features**



### Industrial quality

- Quiet operation
- Dependable, long life

### Elements (not shown)

 Available for both particulate and Water Removal (WR) in double length w/ 2.5 times increased DHC

### **Electrical Cord (not shown)**

- 6 ft. with ON/OFF switch
- Optional 20 ft. cord with retractable reel & mounted power switch with thermal overload protection



### Specifications:

# Maximum Recommended Fluid Viscosity:

5MFP – 3000 SUS (627cSt) 0.85 specific gravity 10MFP – 500 SUS (108 cSt) 0.85 specific gravity

### **Visual Indicator (outlet filter):**

Visual differential type 3-band (clean, change, bypass)

# Filter Bypass Valve Settings (Integral to Element):

Inlet - 3 psid (0.2 bar) Outlet - 35 psid (2.4 bar)

Seal option "B" (standard)

### **Operating Temperature:**

-40°F to +150°F (-40°C to +66°C) Seal option "V" (high temp option) -15°F to +200°F (-26°C to +93°C)

#### **Electrical Service Required:**

5MFP - 110/220 volts, 60/50 Hz, single phase, 8/4 amps 10MFP - 110/220 volts, 60/50 Hz, single phase, 10/5 amps

#### **Electrical Motor:**

5MFP - ½ hp @ 1725 rpm, O.D.P. 10MFP - ¾ hp @ 3450 rpm, O.D.P. Thermal overload protection

#### **Construction:**

Cart frame – Steel
Filter head – Aluminum
Filter bowl – Steel
Hoses – PVC (Std.)
EPDM (high temp option)
Wands – PVC (Std.)
Steel tube (high temp option)

### Weight:

110 lbs. (45.4kg)

### Dimensions:





### Typical Fluid Cleanliness Level Requirements

Many manufacturers of hydraulic components have established fluid cleanliness levels for their components. Using a portable filter cart can be a very effective way to reach and maintain these cleanliness levels.

Component	ISO Cleanliness Level
Servo control valves	16/14/11
Proportional valves	17/15/12
Vane and piston pumps/motors	18/16/13
Directional and pressure control valves	18/16/13
Gear pumps/motors	19/17/14
Flow control valves cylinders	20/18/15
New fluid	20/18/15

# Filter Cart Element Performance

Media Code	Filter Media	Capacity (Grams)
40W	Woven Wire	*
40SA	Synthetic	*
20Q	Microglass III	140
10Q	Microglass III	135
05Q	Microglass III	130
02Q	Microglass III	110



Notes: Multipass test run @ 80 gpm to 50 psid terminal - 5 mg/l BUGL.

### Filter Cart Performance

Fluid cleanliness levels are a function of initial contamination levels, contamination ingression rates, reservoir size and filter element efficiency. The chart below lists approximate time requirements to achieve certain cleanliness levels based on the assumptions noted.

Reservoir Capacity (Gallons)	Time Required (Hours)	Projected Cleanliness Level (ISO)
50	0.5	20/18/15
50	1.0	17/15/12
50	2.5	16/14/11
100	1.5	18/16/13
100	2.5	17/15/12
100	4.0	16/14/11
200	2.5	19/17/14
200	3.5	18/16/13
200	5.0	17/15/12

#### Notes:

The results in the chart are based on the following assumption:

- 1. Initial contamination level is 500,000 particles greater than 10 micrometers per 100 ml of fluid (10MFP cart).
- 2. Inlet filter fitted with 40SA element; outlet with 20Q element.
- 3. System ingression rate equal to 1 X 10<sup>6</sup> particles greater than 10 micrometers entering the system per minute.

## Par-Gel™ Media Water Capacity

Model	Fluid Viscosity	Capacity
5MFP	75 SUS 200 SUS	600 ml 420 ml
10MFP	75 SUS 200 SUS	500 ml 300 ml

#### Notes:

- Par-Gel™ elements are designed to remove "free water", which is defined as water that is above a particular fluid's saturation level.
- Capacity is very dependent on flow rate and viscosity. Not recommended with fluids in excess of 500 SUS.



#### Assembly

- Install hoses to inlet and outlet filters by threading the hose end with the straight thread o-ring seal fitting into the filter flange.
- 2. Connect the PVC tube wands to the swivel fitting on the hose end. When servicing the PVC tube wand, do not over-torque the metal fittings going into the PVC coupling. Over-torque will result in cracking the coupling. Generally, 1/4 turn beyond hand-tight is sufficient.

#### **Operating Instructions**

- 1. Insert the inlet wand assembly into the supply fluid receptacle (drum/reservoir). The RFP filter is the inlet filter.
- Insert the outlet wand assembly into the clean fluid receptacle (drum/reservoir). The ILP fllter is the outlet filter.

**Caution:** Do not kink the hose assemblies, this may result in excessive vacuum or pressure at the pump.

- 3. Verify that the ON/OFF switch is OFF and plug the cord into the proper grounded power source (3 wire).
- 4. Turn switch to ON position and check outlet wand for oil flow. Allow 30 to 60 seconds for filters to fill with oil. If repeated attempts to obtain oil flow fail, check pump inlet fittings for tightness, remove inlet filter access cover and verify the cover sealing o-ring is in place. For very viscous fluids it may be necessary to pour 1 or 2 quarts of fluid into the RFP inlet filter housing to prime pump initially.

- 5. The condition of the filter element should be monitored by observing the cleanliness indicator on the outlet filter. When the indicator is in the CHANGE position, both inlet and outlet filter elements MUST be replaced to prevent fluid from going through the bypass in the filters.
- 6. The inlet filter element is provided with a 3PSI bypass spring, and prevents the pump from cavitating if the element is not changed. The outlet filter element is provided with a 35PSI bypass spring to prevent excessive pressure which may be harmful to personnel or to the filter cart.

Warning: The filter bypass spring acts as a relief valve for the pump. Do not restrict the outlet hose with a shut-off valve which will defeat the function of the bypass valve, causing excessive pressure, which may be harmful to personnel or to the filter cart.

 The cleanliness indicator works on differential pressure and will indicate the condition of the element (CLEAN, CHANGE, or BYPASS).

**NOTE:** The filter cart must be in operation for the indicator to read properly.

#### **Maintenance Instructions**


- Turn switch to OFF position and unplug cord from electrical outlet.
- 2. Remove tube wands from oil to prevent siphoning.
- Loosen hex head screws on filter cover. Turn cover to clear screws, remove cover.
- 4. Pull filter element from the filter head.
  - a) Replace the synthetic or Microglass III elements.
     Verify replacement.
  - b) Wire mesh elements can be cleaned. Ultrasonic cleaners provide best results.
- Install element in filter
  housing. Make sure element
  o-rings seat properly into the
  head, making sure that the
  notch on the element lines up
  with the notch in the head.
- 6. Inspect the cover o-ring and replace if necessary.
- 7. Replace cover and tighten hex head screws until they are snug. Do not over-torque these screws. Do not interchange the inlet filter cover with the outlet filter cover. (The inlet filter has a "RFP" prefix, the outlet filter has a "ILP" prefix).

### Trouble Shooting

TI OUDIO C	on looting	
Problem	Cause	Solution
Does not start	ON/OFF Switch	Turn switch ON, replace switch if defective
	No electrical power	Plug in cart
	Defective motor	Replace
No oil flow or erratic	Filter housing not filled with oil	Allow pump to run 30 to 60 seconds
pump noise	Suction leak	Check tightness of inlet fittings
		Check o-ring in inlet filter cover for nicks
		Kink or restriction in inlet hose
		Add 1 or 2 quarts of oil to inlet filter
	Defective pump	Replace pump
Indicator reads	Element dirty	Replace or clean elements (both filters)
CHANGE or BYPASS	Oil extremely cold or viscous	Change element to coarser micron rating
Indicator does not	No outlet element	Install element
seem to move	40 micron element installed in outlet filter	Check cart model number to verify correct element. The inlet filter has a rating RFP prefix; the outlet filter has an ILP prefix



# Filter Cart Replacement Parts



Item No.	Part No.	Description	Qty
1	928690	Frame	1
2	940980	Pipe Reducer Fitting	1
3	940979	Tube Fitting	1
4	937526	Suction Tube Assy.	1
5	928652	Adapter Fitting	1
6	928731	Pump	1
7	940977	Adapter Fitting	1
8	928650	Wheel	2
9	928653	Axle	1
10	928678	Motor 10MFP	1
10	929692	Motor 5MFP	1
11	937527	Discharge Tube Assy.	1
12	940978	Tube Fitting	1

Item N	o. Part No.	Description	Qty
13	928649	Cord Cleat	1
Opt 13	928623	Cord Reel	1
14	RFP-2-**-B-PP-3-YN-F9-1	Inlet Filter – Nitrile	1
14	RFP-2-**-V-PP-3-YN-F9-1	Inlet Filter – Fluorocarbon	1
15	928784	Tube Wand Assy. – Seal Option B	2
15	928620	Tube Wand Assy. – Seal Option V	2
16	ILP-2-**-B-VP-35-YN-YN-1	Outlet Filter – Nitrile	1
16	ILP-2-**-V-VP-35-YN-YN-1	Outlet Filter – Fluorocarbon	1
17	928663	Hose Assy. – Seal Option B	2
17	928621	Hose Assy. – Seal Option V	2
18	928651	Handle Grip	2
19	See Chart**	Element, (1) Inlet & (1) Outlet	2
**Refer	to chart on How to Order	r page.	



# **How to Order**

Select the desired symbol (in the correct position) to construct a model code.

### **Example:**

BOX 1	BOX 2	вох з	BOX 4	BOX 5	BOX 6	вох 7	вох в
10MFP	2	405A	10Q	В	VP	I	1

	sic Assembly Description
5MFP	5 GPM (3000 SUS MAX.)
10MFP	10 GPM (500 SUS MAX.)

BOX 2: Le Symbol	ength Description	
2	Double	

BOX 3: Inlet Filter Element Symbol Description	
40SA	Synthetic, 40 micron
40W	Stainless Steel Mesh, 40 micron nominal
20Q	Microglass III, 20 micron

Please note the bolded options reflect standard options with a reduced leadtime. Consult factory on all other lead-time options.

BOX 4: 0 Symbol	outlet Filter Element Description
02Q	Microglass III, 2 micron
05Q	Microglass III, 5 micron
10Q	Microglass III, 10 micron
20Q	Microglass III, 20 micron
WR	Par-Gel™ Water Removal
WH	Par-Geriii water Remova

BOX 5: Seals				
Symbol	Description			
В	Nitrile (NBR)			
V	High temperature option (FKM/EPDM)			

BOX 6: Indicator Symbol Description		
VP	Visual indicator, 3-band (mounted on Outlet Filter only)	

BOX 7: Bypass Symbol Description			
I	35 PSID (2.4 bar) (outlet filter element)		

BOX 8: Options Symbol Description		
1	None	
6	20' electrical cord (retractable reel)	
9	Visual indicator on Inlet Filter	

### Replacement Elements

	Nitrile Seals		Fluorocarbon Seals	
Media	Inlet Filter (3 psid integral bypass)	Outlet Filter (35 psid integral bypass)	Inlet Filter (3 psid integral bypass)	Outlet Filter (35 psid integral bypass)
02Q	N/A	937397Q	N/A	937405Q
05Q	N/A	937398Q	N/A	937406Q
10Q	N/A	937399Q	N/A	937407Q
20Q	940971Q	937400Q	940974Q	937408Q
40SA	940802	N/A	940972	N/A
40W	940803	N/A	940973	N/A
WR	N/A	940734	N/A	940736